



# TECHNICAL DATA SHEETS

FOR

<b>WET LOOK WL5.....</b>	<b>2</b>
<b>WET LOOK JSS.....</b>	<b>7</b>



## WET LOOK (WL5)

PAVING PROTECTOR - GLOSS FINISH - SOLVENT BASED



### UPDATE

**February 4, 2019**

Make sure that you have an up-to-date technical data sheet in hand by consulting our website: [techniseal.com](http://techniseal.com)  
U.S.A. and Canada: dial 1 800 465-7325  
Others: dial (514) 523-8324 (Canada)

### APPLICATIONS

- For concrete pavers, wet-cast pavers, natural stone, aggregates and permeable systems
- Recommended for driveways, parking lots, patios and walkways

### PROPERTIES

- Enhances the color of pavers
- Stabilizes Sand or Aggregate Joints
- Stain guard
- Forms a protective film

### DESCRIPTION

Made of acrylic and plasticizers, WET LOOK (WL5) Protector is specially designed to protect and stop the movement of aggregates (permeable paver joints\*) or sand (conventional paver joints) while enhancing the color of pavers or natural Stone. With no significant impact on permeability of aggregates, it prevents deteriorations due to chemical products such as de-icing salts, while providing resistance to acids and alkalis. Its transparent film stops the penetration of contaminants, facilitating the maintenance of pavers.

\*Refer to paver manufacturer recommendations for aggregate specifications and permeable paver systems.

### DIRECTIONS

#### APPLICATION TO CONCRETE PAVERS

##### BEFORE YOU BEGIN

**ALWAYS TEST** on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped or poured concrete.
- Do not apply to polished materials.
- Apply only to a bare material or to materials previously sealed with WL5, WL4 or WLWR Protector from Techniseal. Wait until the Protector is worn to recoat the surface (minimum 2 years).
- With the appropriate Techniseal stripper, remove any unknown coating that was previously applied.
- Wear adequate protective clothing and an OSHA approved respirator for acetone.

**SURFACE PREPARATION (ESSENTIAL)**

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface with Techniseal® Paver Prep (efflorescence cleaner), as directed on product label.

**APPLICATION****Application Conditions:**

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours
- No rain forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

**Necessary Tools:**

- Solvent-resistant low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice))
- Techniseal® Slit-Foam Roller or 3/8" polyester nap rollers and solvent resistant paint tray

Do not dilute. Shake well or stir product before and during application.

**Sprayer Application (Best Practice):** Work in sections of no more than 50 sq. ft. **Saturate** surface with a coat of Protector. With a roller, remove the excess from the surface before it dries (this step is critical for textured pavers). Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

**Roller Application:** Work in sections of no more than 50 sq. ft. **Saturate** the surface with a coat of Protector, avoiding accumulation of excess product (this step is critical for textured pavers). Maintain a wet edge to prevent overlap marks.

**CAUTION**

- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector, like any film forming coating, carries a small risk of trapping efflorescence beneath its film. Consult the paver manufacturer or contact Techniseal® at 1-800-465-7325 for more information.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Inadequate surface cleaning can result in uneven finish.
- This product will make the surface more slippery when wet. If slipping is a concern, consider adding SureFoot anti-slip grit (60102089) to the Protector before the application.
- An over-accumulation of product could lead to surface whitening.
- Wait 30 days after the installation of new polymeric sand before sealing the pavers.
- Extreme climate or heavy traffic can limit product longevity.

**APPLICATION TO WET-CAST PAVERS****BEFORE YOU BEGIN**

**ALWAYS TEST** on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped or poured concrete.
- Do not apply to polished materials.
- Apply only to a bare material or to materials previously sealed with WL5 or WCS Protector from Techniseal.
- Wait until the Protector is worn to recoat the surface (minimum 2 years).
- With the appropriate Techniseal stripper, remove any unknown coating that was previously applied.
- Wear adequate protective clothing and an OSHA approved respirator for acetone.

**SURFACE PREPARATION (ESSENTIAL)**

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface following recommendations from the wet-cast paver manufacturer. Once installed, a layer of efflorescence-like dust can form on the surface of some wet-cast pavers after a few days. It is critical that this layer be removed prior to applying the Protector.

## APPLICATION

### Application Conditions:

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours
- No rain forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

### Necessary Tools:

- Solvent-resistant low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- Techniseal® Slit-Foam Roller or 3/8" polyester nap rollers and solvent resistant paint tray

Do not dilute. Shake well or stir product before and during application.

**Sprayer Application (Best Practice):** Work in sections of no more than 50 sq. ft. **Saturate** surface with a coat of Protector. With a roller, immediately remove the excess from the surface before it dries (this step is critical for textured pavers). Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

**Roller Application:** Work in sections of no more than 50 sq. ft. **Saturate** the surface with a coat of Protector, avoiding accumulation of excess product (this step is critical for textured pavers). Maintain a wet edge to prevent overlap marks.

## CAUTION

- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector, like any film forming coating, carries a small risk of trapping efflorescence beneath its film. Consult the paver manufacturer or contact Techniseal® at 1-800-445-7325 for more information.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Inadequate surface cleaning can result in uneven finish.
- This product will make the surface more slippery when wet. If slipping is a concern, consider adding SureFoot anti-slip grit (60102089) to the Protector before the application.
- An over-accumulation of product could lead to surface whitening.
- Wait 30 days after the installation of new polymeric sand before sealing the pavers.
- Extreme climate or heavy traffic can limit product longevity.

## APPLICATION TO NATURAL STONE

### BEFORE YOU BEGIN

**ALWAYS TEST** on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped or poured concrete.
- Do not apply to polished materials.
- Apply only to a bare material or to materials previously sealed with WL5 Protector from Techniseal.
- Wait until the Protector is worn to recoat the surface (minimum 2 years).
- With the appropriate Techniseal stripper, remove any unknown coating that was previously applied.
- Wear adequate protective clothing and an OSHA approved respirator for acetone.

### SURFACE PREPARATION (ESSENTIAL)

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface following recommendations from the natural stone manufacturer.

## APPLICATION

### Application Conditions:

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 86°F.
- It is important that the temperature remains over 50°F for the next 24 hours
- No rain forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

**Necessary Tools:**

- Solvent-resistant low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- Techniseal® Slit-Foam Roller or 3/8" polyester nap rollers and solvent resistant paint tray

Do not dilute. Shake well or stir product before and during application.

**Sprayer Application (Best Practice):** Work in sections of no more than 50 sq. ft. **Saturate** surface with a coat of Protector. With a roller, immediately remove the excess from the surface before it dries (this step is critical for textured stones). Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

**Roller Application:** Work in sections of no more than 50 sq. ft. **Saturate** the surface with a coat of Protector, avoiding accumulation of excess product (this step is critical for textured stones). Maintain a wet edge to prevent overlap marks.

**CAUTION**

- All natural stones are unique and will age differently. This Protector will not prevent the aging phenomenon from occurring.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- An over-accumulation of product could lead to surface whitening.
- Inadequate surface cleaning can result in uneven finish.
- This product will make the surface more slippery when wet. If slipping is a concern, consider adding SureFoot anti-slip grit (60102089) to the Protector before the application.
- Wait 30 days after the installation of new polymeric sand before sealing the pavers.
- Extreme climate or heavy traffic can limit product longevity.

**TO STABILIZE SAND OR AGGREGATES JOINTS****BEFORE YOU BEGIN**

**ALWAYS TEST** on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped or poured concrete.
- Do not apply to polished materials.
- Apply only to a bare material or to materials previously sealed with WL5, WL4 or WLWR Protector from Techniseal.
- Wait until the Protector is worn to recoat the surface (minimum 2 years).
- With the appropriate stripper, remove any unknown coating that was previously applied.
- Wear adequate protective clothing and an OSHA approved respirator for acetone.

**SURFACE PREPARATION (ESSENTIAL)**

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. **Concrete pavers (dry-cast):** Prepare the entire surface with Techniseal® Paver Prep (efflorescence cleaner), as directed on product label. **Wet-cast pavers:** Prepare the entire surface following recommendations from the wet-cast paver manufacturer. Once installed, a layer of efflorescence-like dust can form on the surface of some wet-cast pavers after a few days. It is critical that this layer be removed prior to applying the Protector. **Note:** When rinsing a cleaning product, use an appropriate water pressure that will not displace aggregates.

**APPLICATION****Application Conditions:**

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours.
- No rain forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

**Necessary Tools:**

- Solvent-resistant low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- Techniseal® Slit-Foam Roller or 3/8" polyester nap rollers and solvent resistant paint tray

Do not dilute. Shake well or stir product before and during application.

Work in sections of no more than 50 sq. ft. Using the sprayer, **saturate** a section with a heavy coat of Protector. With the roller, immediately push the excess liquid into the joints before it dries. Joint flooding is important to obtain proper stabilization. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks. Avoid displacing the aggregates with the roller.

Second Coat: Once the surface is dry to the touch (+/- 2 hours), a second coat can be applied to porous pavers to deepen the wet look, obtain a glossier finish and improve the stain protection. Apply the second coat following the same method but using a lighter coat of sealant. **Do not apply** a second coat on **wet-cast or non-porous pavers** as this will result in a slippery surface

**CAUTION**

- Frequent and aggressive maintenance could affect aggregate joint binding.
- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector, like any film-forming coating, carries a small risk of trapping efflorescence beneath its film. Consult the paver manufacturer or contact Techniseal 1 800 465-7325 for more information.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- This product will make the surface more slippery when wet. If potential slipperiness is a cause for concern, use SureFoot anti-slip grit from Techniseal® (60102089).
- An over-accumulation of product could lead to surface whitening.
- Extreme climate or heavy traffic can limit product longevity.

**TRAFFIC**

Pedestrian: 24 h. / Vehicular: 48 to 72 h. Block access during that period.

**COVERAGE**

As a concrete, wet-cast paver or natural stone sealer: single-coat application. 1 gal. covers up to 150 sq. ft. / 5 gal. cover up to 750 sq. ft.

As a joint stabilizer: 1 gal. covers from 50 to 125 sq. ft./ 5 gal. cover from 250 to 625 sq. ft.

Coverage will depend on joint width and type as well as surface porosity.

**STORAGE AND SHELF LIFE**

Store in a cool, dry place.

**CLEANING & DISPOSAL**

Wash tools with lacquer thinner. Consult your retailer or municipality regarding the disposal of empty containers or unused product.

**PACKAGING**

Product Code	Size	Units per box	Units per pallet
60301532	1 gal	2	180
60301533	5 gal.	-	48
60102004	55 gal. (special order)	-	4

**SHIPPING**

**Land and Sea**

UN1993 ; Flammable liquid, n.o.s. (Acetone) ; Class 3 ; GE/PG : II

**HANDLING AND SAFETY**

For information and advice regarding transportation, handling, storage, first aid and disposal of chemicals products, users should refer to the actual Safety Data Sheet containing physical, ecological, toxicological and other safety-related data.

**KEEP OUT OF THE REACH OF CHILDREN**  
**EMERGENCY PHONE: CANUTEC (613) 996-6666**

## LIMITED WARRANTY

---

Having no control over the use of the products, Techniseal® does not guarantee finished work. Replacement of any defective product shall be the buyer's sole remedy under this warranty. A proof of purchase will be required for any claim. Before using this product, user shall determine the suitability of the product for its intended use, and user alone assumes all risks and liability whatsoever in connection therewith. User shall test product in a small inconspicuous area (approx. 4 sq. ft.) under projected conditions of use. In the event that no test was carried out, the warranty will only apply to 4 sq. ft. This limited warranty excludes any liability for any consequential, incidental, indirect or special damages. Except for the limited warranty described above, manufacturer specifically disclaims and excludes any other express warranty, any implied warranty of merchantability of goods, and implied warranty of fitness of goods for any particular purpose.



## WET LOOK (JSS)

PAVING PROTECTOR - GLOSS FINISH - SOLVENT BASED



### UPDATE

**February 4, 2019**

Make sure that you have an up-to-date technical data sheet in hand by consulting our website: [techniseal.com](http://techniseal.com)  
U.S.A. and Canada: dial 1 800 465-7325  
Others: dial (514) 523-8324 (Canada)

### APPLICATIONS

- For concrete pavers, wet-cast pavers, natural stone, aggregates and permeable systems
- Recommended for driveways, parking lots, patios and walkways

### PROPERTIES

- Enhances the color of pavers
- Stabilizes sand or aggregate joints
- Stain guard
- Forms a protective film

### DESCRIPTION

Made of acrylic and plasticizers, WET LOOK (JSS) Protector is specially designed to protect and stop the movement of aggregates (permeable paver joints\*) or sand (conventional paver joints) while enhancing the color of pavers or natural stone. With no significant impact on permeability of aggregates, it prevents deteriorations due to chemical products such as de-icing salts, while providing resistance to acids and alkalis. Its transparent film stops the penetration of contaminants, facilitating the maintenance of pavers.

\*Refer to paver manufacturer recommendations for aggregate specifications and permeable paver systems.

### DIRECTIONS

#### APPLICATION TO CONCRETE PAVERS

##### BEFORE YOU BEGIN

**ALWAYS TEST** on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped or poured concrete. • Do not apply to polished materials. • Apply only to a bare material or to materials previously sealed with JSS Protector from Techniseal. • Wait until the Protector is worn to recoat the surface (minimum 2 years). • With the appropriate Techniseal stripper, remove any unknown coating that was previously applied. • Wear adequate protective clothing and an OSHA approved respirator for acetone.



**SURFACE PREPARATION (ESSENTIAL)**

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface with Techniseal® Paver Prep (efflorescence cleaner), as directed on product label.

**APPLICATION****Application Conditions:**

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours
- No rain forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

**Necessary Tools:**

- Solvent-resistant low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- 3/8" polyester nap rollers and paint tray

Do not dilute. Shake well or stir product before and during application.

**Sprayer Application (Best Practice):** Work in sections of no more than 50 sq. ft. **Saturate** surface with a coat of Protector. With a roller, immediately remove the excess from the surface before it dries (this step is critical for textured pavers). Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

**Roller Application:** Work in sections of no more than 50 sq. ft. **Saturate** the surface with a coat of Protector, avoiding accumulation of excess product (this step is critical for textured pavers). Maintain a wet edge to prevent overlap marks.

**Second coat:** Once the surface is dry to the touch (+/- 1 hour), a second coat can be applied for a more pronounced wet look and gloss. Use the same method but apply less product. Do not apply a second coat to pavers that are not very porous as this could result in a slippery surface.

**CAUTION**

- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector, like any film forming coating, carries a small risk of trapping efflorescence beneath its film. Consult the paver manufacturer or contact Techniseal® at 1-800-465-7325 for more information.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Inadequate surface cleaning can result in uneven finish.
- This product will make the surface more slippery when wet. If slipping is a concern, consider adding SureFoot anti-slip grit (60102089) to the Protector before the application.
- An over-accumulation of product could lead to surface whitening.
- Wait 30 days after the installation of new polymeric sand before sealing the pavers.
- Extreme climate or heavy traffic can limit product longevity.

**APPLICATION TO WET-CAST PAVERS**

---

**BEFORE YOU BEGIN**

**ALWAYS TEST** on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped or poured concrete.
- Do not apply to polished materials.
- Apply only to a bare material or to materials previously sealed with JSS Protector from Techniseal.
- Wait until the Protector is worn to recoat the surface (minimum 2 years).
- With the appropriate Techniseal stripper, remove any unknown coating that was previously applied.
- Wear adequate protective clothing and an OSHA approved respirator for acetone.

**SURFACE PREPARATION (ESSENTIAL)**

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface following recommendations from the wet-cast paver manufacturer. Once installed, a layer of efflorescence-like dust can form on the surface of some wet-cast pavers after a few days. It is critical that this layer be removed prior to applying the Protector.

## APPLICATION

### Application Conditions:

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours.
- No rain forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

### Necessary Tools:

- Solvent-resistant low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- 3/8" polyester nap rollers and paint tray

Do not dilute. Shake well or stir product before and during application.

**Sprayer Application (Best Practice):** Work in sections of no more than 50 sq. ft. **Saturate** surface with a coat of Protector. With a roller, immediately remove the excess from the surface before it dries (this step is critical for textured pavers). Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

**Roller Application:** Work in sections of no more than 50 sq. ft. **Saturate** the surface with a coat of Protector, avoiding accumulation of excess product (this step is critical for textured pavers). Maintain a wet edge to prevent overlap marks.

## CAUTION

- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector, like any film forming coating, carries a small risk of trapping efflorescence beneath its film. Consult the paver manufacturer or contact Techniseal® at 1-800-465-7325 for more information.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- Inadequate surface cleaning can result in uneven finish.
- This product will make the surface more slippery when wet. If slipping is a concern, consider adding SureFoot anti-slip grit (60102089) to the Protector before the application.
- An over-accumulation of product could lead to surface whitening.
- Wait 30 days after the installation of new polymeric sand before sealing the pavers.
- Extreme climate or heavy traffic can limit product longevity.

## APPLICATION TO NATURAL STONE

### BEFORE YOU BEGIN

**ALWAYS TEST** on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped or poured concrete.
- Do not apply to polished materials.
- Apply only to a bare material or to materials previously sealed with JSS Protector from Techniseal.
- Wait until the Protector is worn to recoat the surface (minimum 2 years).
- With the appropriate Techniseal stripper, remove any unknown coating that was previously applied.
- Wear adequate protective clothing and an OSHA approved respirator for acetone.

### SURFACE PREPARATION (ESSENTIAL)

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Prepare the entire surface following recommendations from the stone manufacturer.

## APPLICATION

### Application Conditions:

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours
- No rain forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

**Necessary Tools:**

- Solvent-resistant low-pressure airless sprayer (< 50 psi) or pump sprayer (best practice)
- 3/8" polyester nap rollers and paint tray

Do not dilute. Shake well or stir product before and during application.

**Sprayer Application (Best Practice):** Work in sections of no more than 50 sq. ft. **Saturate** surface with a coat of Protector. With a roller, immediately remove the excess from the surface before it dries (this step is critical for textured stones). Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks.

**Roller Application:** Work in sections of no more than 50 sq. ft. **Saturate** the surface with a coat of Protector, avoiding accumulation of excess product. Maintain a wet edge to prevent overlap marks.

**CAUTION**

- All natural stones are unique and will age differently. This Protector will not prevent the aging phenomenon from occurring.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- An over-accumulation of product could lead to surface whitening.
- Inadequate surface cleaning can result in uneven finish.
- This product will make the surface more slippery when wet. If slipping is a concern, consider adding SureFoot anti-slip grit (60102089) to the Protector before the application.
- Wait 30 days after the installation of new polymeric sand before sealing the pavers.
- Extreme climate or heavy traffic can limit product longevity.

**TO STABILIZE SAND OR AGGREGATES JOINTS****BEFORE YOU BEGIN**

**ALWAYS TEST** on a small hidden area of approximately 4 sq. ft. to ensure that result meets your expectations (see Warranty).

- Do not apply to stamped or poured concrete.
- Do not apply to polished materials.
- Apply only to a bare material or to materials previously sealed with JSS Protector from Techniseal.
- Wait until the Protector is worn to recoat the surface (minimum 2 years).
- With the appropriate stripper, remove any unknown coating that was previously applied.
- Wear adequate protective clothing and an OSHA approved respirator for acetone.

**SURFACE PREPARATION (ESSENTIAL)**

1. Cover vegetation, vehicles and adjacent surfaces that are not to be treated.
2. Remove stains with the appropriate Techniseal® stain removers.
3. Concrete pavers (dry-cast): Prepare the entire surface with Techniseal® Paver Prep (efflorescence cleaner), as directed on product label. Wet-cast pavers: Prepare the entire surface following recommendations from the wet-cast paver manufacturer. Note: When rinsing a cleaning product, use an appropriate water pressure that will not displace aggregates.

**APPLICATION****Application Conditions:**

- Surface must be clean, dry and warm to the touch.
- Temperature must be between 50 and 85°F.
- It is important that the temperature remains over 50°F for the next 24 hours.
- No rain forecasted for the next 24 hours.
- Sprinkler system must be turned off.
- Use a consistent application method over entire surface.

**Necessary Tools:**

- Solvent-resistant low-pressure airless sprayer (< 50 psi) or pump sprayer
- 3/8" polyester nap rollers and paint tray

Do not dilute. Shake well or stir product before and during application.

Work in sections of no more than 50 sq. ft. Using the sprayer, **saturate** a section with a heavy coat of Protector. With the roller, immediately push the excess liquid into the joints before it dries. Joint flooding is important to obtain proper stabilization. Repeat for subsequent sections, maintaining a wet edge to prevent overlap marks. Avoid displacing the aggregates with the roller.

**Second Coat:** Once the surface is dry to the touch (+/- 2 hours), a second coat can be applied to porous pavers to deepen the wet look, obtain a glossier finish and improve the stain protection. Apply the second coat following the same method but using a lighter coat of sealant. **Do not apply** a second coat on **wet-cast or non-porous pavers** as this will result in a slippery surface

**CAUTION**

- Frequent and aggressive maintenance could affect aggregate joint binding.
- Any new concrete product has the potential to produce efflorescence (whitish salts) on its surface. This Protector, like any film-forming coating, carries a small risk of trapping efflorescence beneath its film. Consult the paver manufacturer or contact Techniseal 1 800 465-7325 for more information.
- Do not attempt sprayer application on windy days.
- Do not apply this product over a blotchy or hazed surface.
- This product will make the surface more slippery when wet. If potential slipperiness is a cause for concern, use SureFoot anti-slip grit from Techniseal® (60102089).
- An over-accumulation of product could lead to surface whitening.
- Extreme climate or heavy traffic can limit product longevity.

**TRAFFIC**

Pedestrian: 24 h. / Vehicular: 48 to 72 h. Block access during that period.

**COVERAGE**

As a concrete paver, wet-cast paver or natural stone sealer: single-coat application. 1 gal. covers up to 150 sq. ft. / 5 gal. cover up to 750 sq. ft.

As a joint stabilizer: 1 gal. covers from 50 to 125 sq. ft./ 5 gal. cover from 250 to 625 sq. ft.

Coverage will depend on joint width and type as well as surface porosity.

**STORAGE AND SHELF LIFE**

Store in a cool, dry place.

**CLEANING & DISPOSAL**

Wash tools with lacquer thinner. Consult your retailer or municipality regarding the disposal of empty containers or unused product.

**PACKAGING**

Product Code	Size	Units per box	Units per pallet
60300431	1 gal	2	180
60300432	5 gal.	-	48
60101978	55 gal. (special order)	-	4

**SHIPPING**

**Land and Sea**

UN1993 ; Flammable liquid, n.o.s. (Acetone, ethylbenzene); Class 3 ; PG : II

**HANDLING AND SAFETY**

For information and advice regarding transportation, handling, storage, first aid and disposal of chemicals products, users should refer to the actual Safety Data Sheet containing physical, ecological, toxicological and other safety-related data.

**KEEP OUT OF THE REACH OF CHILDREN**  
**EMERGENCY PHONE: CANUTEC (613) 996-6666**

## LIMITED WARRANTY

---

Having no control over the use of the products, Techniseal® does not guarantee finished work. Replacement of any defective product shall be the buyer's sole remedy under this warranty. A proof of purchase will be required for any claim. Before using this product, user shall determine the suitability of the product for its intended use, and user alone assumes all risks and liability whatsoever in connection therewith. User shall test product in a small inconspicuous area (approx. 4 sq. ft.) under projected conditions of use. In the event that no test was carried out, the warranty will only apply to 4 sq. ft. This limited warranty excludes any liability for any consequential, incidental, indirect or special damages. Except for the limited warranty described above, manufacturer specifically disclaims and excludes any other express warranty, any implied warranty of merchantability of goods, and implied warranty of fitness of goods for any particular purpose.